
QuickStart

MobileCommunicationManager (MCM)



This Quick Start introduces you to the main features of the Mobile Communication Manager (MCM) software:

- Installation
- Basic functions
- First call

For detailed information, read the *Manual*. You will find the PDF file for the *Manual* on the CD-ROM supplied by Option International.

Installation

Connect your Handheld PC to your Desktop PC.

On the CD-ROM you will find folders containing the MCM in the relevant language. Choose the folder with the language you require. Please note that the installation application is only available in English. Irrespective of this, the MCM program is installed on your HPC in the language you have chosen. First make a current backup of the data of your HPC.

Next, insert the CD-ROM which Optional International supplied together with the FirstFone GSM PC Card into your PC.

Double-click the ***MCMinst.exe*** file.

You have now loaded the MCM program onto the HPC. By default, the ***MCM.exe*** file is stored in the ***Windows, Programs, Communication*** folder.

Install your SIM card and push the GSM PC Card into the slot of your HPC. Connect your earphone.

Start

Enter your PIN, and wait until the network search has been successfully completed and the name of your provider appears on the screen.



Start the MCM by tapping the ***MCM symbol*** twice.

Main screen:

Basic functions of the MCM at first glance

This leaflet provides an overview of the most important functions and buttons of the MCM. For a detailed description, refer to the *Manual*.



Info Button and Settings

By tapping the **Info (i)** button, you can define your settings via the **Settings** menu item (e. g. call diversions or call blocks).



Dialing

You can enter phone numbers by using the keyblock, the keyboard, or the **Dial** popup menu.



Lift/Replace Handset

You can use the **Lift Handset** button to accept incoming calls or to activate the dialing process.



By tapping the **Replace Handset** button, you can end a call.

SMS

The **SMS** button lets you create SMS messages quickly and easily, and list SMS messages you have received.



New SMS Messages and Calls During Absence

Tap the respective option with the stylus, and you will receive lists of SMS messages you have received and of unanswered calls.

Search for Network/Provider

The current service provider is displayed here.

Signal Strength and Headset Volume

The bar at the top left of the window displays the current reception signal strength. Use the **Volume** slider control to change the volume of your headset.

First Telephone Call

If you have correctly installed the GSM PC Card and have logged on to the mobile phone network of your provider you are now ready to make your first call.

Type in the telephone number you require using the keyboard of your Handheld PC.

You will now see the number you have typed and a head or company symbol on the main screen.

When you have entered the full number, tap the **Lift Handset** button.

When the person you are calling lifts the handset, the **Connection Active** symbol appears and the duration of the call is shown.

To end the call, tap the **Replace Handset** button.

+490000100002
dialing



Company
ringing



+49000200002
1:15

